ADS |Universal Dimmer

Installation and programming manual



TISAIR



ADS Wiring Diagram



ADS |Universal Dimmer

ADS-1D-1Z


Light
Configuration key
WIFI Signal Indicator
4P

Installation Steps



Warning

You should configure the panel outputs in the correct mode before using it, as lights, curtain or air conditions from your application setting

Operation Instruction

Download and install APP

Android

IOS

Open the APP interface and click the Settings icon



Enter the administrator account and password,
default username: user
default password: tis777

Enter the settings interface, select "TIS AIR CONFIG".

Power the smart switch, press the Configuration TIS key for 5 second till it starts blinking



Configuration key
WIFI Signal Indicator

Enter your WiFi router password then click "SEARCH", the device will be configured within 50 seconds



Configuration key will be turned to blue once it successfully configured, and the following page will be shown. click on "GO TO MODIFY "



Enter your panel setting

Device comment: any comment like panel location, it helps programmer in advanced search and settings in Device Search software.

Net id & Device ID:
Enter unique Subnet ID and Device ID for your panel.

MAC ADDRESS:
Each device has its MAC address to use it later in Network Setting to be able to link your mobile to the device and internet remote control setting.

New ADD button function
when you saved the panel to new address it is important to link its touch buttons to control the panel relays new address.



Select Room: press on the select room icon and select the location of where you had installed your panel, if the room is not exist, you can add it from the main setting page.
Channel Icons: press on the channel icon and select the icon from the default library or from your own gallery or just take new picture from your phone.
Channel comment: type the name of your lighting channel.



Blackout Setting
you can set the panel to its last status when powered on or set it to turn on or turn off
Server Info:
you can use one device in each project as master gateway for server internet connection.
Warning: just enable the nearest device to your router as master device for internet connection
Enter your own 4 digit password.
Keep the default setting of TIS Server address as 120.24.42.209. or modify it with other TIS server depends on your country location.

Control Section

select your room and start control
your lights, AC , curtain and others

Warranty Card

From the date of purchase, 1 year limited warranty.
Damage caused by wrong installation , physical damaged , users dismantle repair and other man-made damage will be out of warranty

User name	
Phone number	
Address	
Official Dealer	
Product SN	
Purchase date	
Repairing record	

www.tissmarthome.com